

Malfunctions/damage to stand equipments

Emitted by:	PH Movement
Volume DDS:	3 – Apron Safety
Ref. Par.:	3.12.2

*Section 3.12.2 is updated as follows
(added/updated text highlighted in grey)*

3.12.2. In the event of malfunctions or damage to equipment on the pitch (optical guides, loading bridge, 400 Hz, pre-conditioning, etc.), follow the procedures set out in Volume 1 of this Document to report the event.

If the malfunction has caused potential or actual damage to aircraft and/or injuries, do not move the system, contact CEA-ADR and wait for ADR-ISE Operational Safety to arrive to prepare the necessary reports for investigating the root cause of the event. Furthermore, the system may not be used until it has been put back into operation by ADR maintenance or a specialised company.

Authorisation to move the equipment before the arrival of ADR-ISE Operational Safety is to be considered authorised a priori in the event of the application of the required safety procedures and in cases where there are imminent health and safety requirements for the operators involved.